
How To Cut Cement Board

*How To Cut
Cement
Board*

*Downloaded from
www.remodelicious.com
by Sterling & Conway*

INTRODUCTION: WHY CUTTING CEMENT BOARD REQUIRES THE RIGHT APPROACH

Cement board is a staple material in modern construction, prized for its durability, moisture resistance, and fireproof qualities. Whether you are tiling a bathroom, installing a shower niche, or building an exterior facade, knowing **how to cut cement board** properly is essential for achieving a professional finish. Unlike drywall or

plywood, cement board is abrasive, brittle, and tough on tools. Cutting it incorrectly can lead to jagged edges, cracked panels, or even personal injury. This guide will walk you through every method, tool, and safety precaution you need to master the process. By the end, you will feel confident tackling any cement board project with precision and efficiency.

UNDERSTANDING CEMENT BOARD AND ITS PROPERTIES

Before you pick up a tool, it helps to

understand what makes cement board different from other sheet goods. Cement board is typically composed of Portland cement, sand, and fiberglass mesh reinforcement. This composition gives it remarkable compressive strength and resistance to water damage, mold, and rot. However, it also makes the material heavy, abrasive, and prone to dust generation when cut. The most common brands include HardieBacker, Durock, and WonderBoard, and each may have slight variations in thickness and density. Thicknesses range from 1/4 inch for floor underlayment to 1/2 inch for wall applications, with 1/2 inch being the most common for tiling

projects.

The key challenge when learning **how to cut cement board** is managing the dust. The silica content in cement board creates a fine, hazardous dust when cut. Prolonged inhalation can cause serious respiratory issues, so dust control is not optional. Additionally, the material dulls cutting tools quickly, so using the correct blade or scoring technique is critical. Understanding these properties will guide your choice of cutting method and safety gear.

ESSENTIAL SAFETY PRECAUTIONS BEFORE CUTTING CEMENT BOARD

Safety must be your first priority when working with cement

board. The dust generated during cutting contains crystalline silica, which is a known carcinogen. Even a small project can produce enough airborne particles to pose a risk. Here are the non-negotiable safety measures:

- **Wear a respirator:** Use a NIOSH-approved N95 or P100 respirator, not a simple dust mask. The fine silica particles can bypass standard masks.
- **Use eye protection:** Safety glasses or goggles prevent dust and debris from irritating or damaging your eyes.
- **Wear gloves:** Cement board edges are rough and can cause skin abrasions. Heavy-duty work gloves protect your hands.
- **Protect your hearing:** Power tools used on cement board are loud. Earplugs or earmuffs are recommended.
- **Set up dust control:** Work outdoors or in a well-ventilated area. Use a shop vacuum with a HEPA filter to capture dust at the source, or wet the cutting line slightly to suppress airborne particles.
- **Secure the panel:** Ensure the cement board is properly supported on a

stable work surface to prevent shifting during cutting.

Taking these precautions seriously will keep you safe and make the cutting process smoother. Never rush through safety steps for the sake of speed.

TOOLS AND METHODS FOR CUTTING CEMENT BOARD

There are several effective ways to cut cement board, ranging from simple manual scoring to power tool methods. The best choice depends on the type of cut you need, the quantity of panels, and the tools you have available. Below, we break down each method in detail.

1. Scoring and Snapping : The Most Common Manual Method

The scoring and snapping technique is the go-to method for straight cuts on cement board. It is fast, inexpensive, and produces minimal dust compared to power tools. This method works best for cutting full sheets down to size for walls or floors. Here is how to do it step by

step:

1. **Measure and**

mark: Use a straightedge and a pencil to mark your cut line. A T-square or a level works well for ensuring accuracy.

2. **Score the**

surface: Using a carbide-tipped scoring tool or a utility knife with a carbide blade, run the tool firmly along the straightedge. Apply enough pressure to cut through the fiberglass mesh and into the cement core. Make several passes if needed, but aim for a deep, clean score line.

3. **Snap the**

board: Place the

scored line

directly over the edge of a workbench or a piece of lumber. Apply downward pressure on the waste side to snap the board along the score line. A sharp, clean break should result.

4. **Cut the mesh:**

Use a utility knife to cut the fiberglass mesh on the back side of the board after snapping. This separates the two pieces completely.

Scoring and snapping is ideal for straight cuts and works well for most DIY projects. However, it requires a steady hand and a straightedge. Practice on a scrap piece first if you are new to the

technique.

2. Using a Circular Saw for Long Straight Cuts

For cutting multiple sheets or making very long straight cuts, a circular saw with the correct blade is faster than scoring by hand. The key is to use a **carbide-tipped blade** designed for masonry or fiber cement. A standard wood blade will dull almost immediately. A continuous rim diamond blade is another excellent

option. Here are the steps:

- Set up the saw with the appropriate blade. A 7-1/4 inch carbide-tipped blade with 15 to 20 teeth works well.
- Clamp the cement board securely to a stable work surface.
- Mark your cut line clearly.
- Attach a shop vacuum to the saw's dust port if available. This dramatically reduces airborne dust.
- Cut along the line with a steady, moderate feed rate. Do not force the saw; let the blade do the work.

- Wear all safety gear, especially a respirator and eye protection.

A circular saw produces a cleaner edge than scoring for some applications, but it generates significantly more dust. Wet cutting is an option if you have a wet saw, but it is not always practical on a job site. For most interior work, a circular saw with dust collection is a good balance of speed and cleanliness.

3. Cutting Cement Board

with an Angle Grinder

An angle grinder equipped with a diamond blade is a versatile tool for cutting cement board, especially for curved cuts, notches, or small adjustments. It is not the best choice for long straight cuts, but it excels at detail work. Follow these guidelines:

- Use a 4-1/2 inch or 5 inch angle grinder with a continuous rim diamond blade. A segmented blade may produce a rougher edge.
- Mark your cut line clearly.
- Hold the grinder

with both hands and cut along the line from one edge to the other. Let the weight of the tool do the cutting.

- For curved cuts, make multiple passes, gradually deepening the cut.
- Be aware that an angle grinder creates a lot of dust. Use it outdoors or with a dust shroud connected to a HEPA vacuum.

The angle grinder method is excellent for cutting around pipes, electrical boxes, or odd-shaped openings. However, it requires steady control and practice to avoid wandering off the line.

4. Using a Jigsaw for Curved or Irregular Cuts

A jigsaw can cut curved shapes in cement board, but it requires the right blade and technique. Use a **carbide-grit jigsaw blade** designed for fiber cement or masonry. Standard bi-metal blades will wear out quickly. Here is how to proceed:

- Clamp the board securely to prevent vibration.
- Drill a starting hole if you are making an

interior cut (e.g., for an electrical box). Use a carbide-tipped drill bit.

- Insert the jigsaw blade into the starting hole.
- Cut slowly and steadily. Do not force the saw. Let the blade oscillate at a moderate speed.
- Support the waste piece to prevent it from breaking off prematurely.

A jigsaw is slower than other methods and produces finer dust, but it is invaluable for non-straight cuts. Use a dust extraction attachment if possible.

5. Scoring

with a Cement Board Knife: A Specialize d Tool

There are specialized tools designed specifically for cutting cement board, such as the HardieKnife or similar scoring knives. These tools have a large carbide wheel that scores deeply in one pass. They work on the same principle as the manual scoring method but are ergonomically designed for the task. The process is similar: score, snap, and cut the mesh. These tools

are excellent for reducing fatigue when cutting multiple sheets.

HOW TO CUT CEMENT BOARD FOR SPECIFIC APPLICATIONS

Different projects require different cutting approaches. Here are some common scenarios and the best methods for each.

Cutting Cement Board for a Shower Wall

For shower wall installations, straight cuts are most common. Scoring and snapping

is usually sufficient for full sheets. For cuts around shower valves or faucets, use an angle grinder or jigsaw. Measure carefully and mark the center of the valve hole. Drill a pilot hole if using a jigsaw, or use the grinder to cut a notch from the edge. Dry-fit the piece before applying any adhesive or screws.

Cutting Cement Board for Floor Underlay ment

Floor underlayment typically uses 1/4 inch cement board. Thinner

material is easier to score and snap. Use a straightedge and a carbide scoring tool. For cuts around toilet flanges or floor registers, an angle grinder or jigsaw is best. Ensure the subfloor is clean and flat before laying the cement board.

Cutting Cement Board for Exterior Applications

Exterior cement board siding or sheathing often requires many long cuts. A circular saw with a dust

collection system is the most efficient method. For pieces that require notching around windows or doors, use an angle grinder. Exterior cuts should be clean to ensure proper sealing and weather resistance.

TIPS FOR CLEANER CUTS AND LESS DUST

Regardless of the method you choose, these tips will help you achieve better results:

- **Use a sharp blade or wheel:**
Dull tools increase effort and produce rougher edges. Replace blades as needed.
- **Clamp the board firmly:**
Movement during cutting leads to inaccurate cuts

and chipping.

- **Cut from the finished side:**
For scoring and snapping, always score the side that will be visible. The snap creates a slight break on the back.
- **Wet cutting for dust reduction:**
Lightly misting the cut line with water can suppress dust, but be careful not to soak the board excessively. Water can weaken the cement if allowed to penetrate too much.
- **Deburr edges:**
After cutting, use a sanding block or a file to smooth any

rough edges.

This makes handling safer and improves the fit.

- **Practice on scrap:** If you are trying a new method or tool, practice on a piece of waste material first.

COMMON MISTAKES TO AVOID WHEN CUTTING CEMENT BOARD

Even experienced professionals can make errors. Here are the most common pitfalls and how to avoid them:

- **Using the wrong blade:** A wood-cutting blade on cement board will dull quickly and may overheat. Always

use carbide or diamond blades.

- **Forcing the tool:** Let the tool do the work. Pushing too hard can cause the board to crack or the blade to bind.
- **Skipping safety gear:** Cement dust is hazardous. Never cut without a respirator and eye protection.
- **Not supporting the board:** Cement board is brittle. Ensure the entire panel is supported, especially near the cut line.
- **Measuring once:** Always measure twice

before cutting. Cement board is not forgiving if you make a mistake.

FREQUENTLY ASKED QUESTIONS ABOUT CUTTING CEMENT BOARD

Can you
cut
cement
board
with a
utility
knife?